

**CHEVRON ADJUSTABLE BRACKET**  
**MOUNTING INSTRUCTIONS**  
**(Can accommodate Wa-9 45x60cm & Wa-109 60x75cm signs)**

**Kit Includes**

- 2x CAB Bars
- 2x Left Angle Pieces
- 2x Right Angle Pieces
- 12x 3/8 Washers
- 12x 1 1/4" x 3/8" Bolts
- 12x 3/8" Nuts

**NOTE: Use of steel chevrons will increase weight on u-channel post, consider aluminium chevrons for this application or wooden posts.**

- Step 1.** Preassemble left and right angle pieces to CAB bar, both upper and lower. (Hardware provided) The "cut out" corners of the CAB bar should be on the top.
- Step 2.** Attach CAB bars to post. CAB bar spacing for Wa-9 45x60cm, use 20" centres and for Wa-109 60x75cm, use 24" centres. (Hardware not included)
- Step 3.** Once CAB bars have been installed on post, attach chevrons to the angle pieces. (Hardware included)
- Step 4.** Finally, position signs to achieve the correct observation angle of the signs and tighten the bolts securing the angle pieces to the CAB bar.