


LED Stop/Stop Paddle #134

With a rechargeable lithium ion battery and lightweight durable design



PRODUCT INCLUDES

- LED Paddle
- 220 mAH Lithium Ion rechargeable battery
- USB-C wall charger
- Wrist strap

TECHNICAL SPECIFICATIONS

- Visible up to 1.8 km away
- Constant on & flashing modes
- Runtime 12hrs (flashing) / 6hrs (constant)
- Battery life 3 years
- 1 Year warranty

LED Paddle Instructions

Operation of the LED Paddle

1. Battery should be fully charged before use
2. Grasp the foam handle and hold the paddle upward
3. Press the FLASH/ON/OFF button above the handle to switch between flashing, solid, and off modes
4. To temporarily turn off the paddle, turn the paddle in downward position (with the word STOP upside down). The LEDs will now turn off and you will be in energy saving mode
Return the paddle to the upright position and the LEDs will illuminate automatically
5. When ready for storage, make sure the sign is powered off

Charging Instructions

1. To charge the battery, plug the charger into a 120/240V AC wall outlet
2. Insert the charge into the battery charge port, located at the bottom of the sign handle
3. The LED indicator on the battery will flash red. This indicates that the battery is being charged. A fully discharged battery will take approx 3-4 hours to charge completely
4. When the battery is fully charged the LED indicator will glow solid red. You may disconnect the charger and use the sign

NOTE: Only ever use the included battery or manufacturer's replacement

Battery Replacement

1. Twist the battery to the left (counterclockwise) and pull to remove
2. Insert the new battery and twist right (clockwise) to lock into place
3. Your sign battery also functions as a power bank. Connect a USB cord to the battery power bank USB port to charge other devices

Warranty

All products and accessories are subject to a 1 year warranty from the date of purchase